

Concurso Kaggle

Yolov5 (paso a paso)

1-Yolo v5 - <https://www.kaggle.com/ultralytics/yolov5>

****YOLO (You Only Look Once)**** is a clever convolutional neural network (CNN) for doing object detection in real-time. The algorithm applies a single neural network to the full image, and then divides the image into regions and predicts bounding boxes and probabilities for each region. These bounding boxes are weighted by the predicted probabilities.

2-Versiones Yolo importantes y links documentación

YOLOv5

Shortly after the release of YOLOv4 Glenn Jocher introduced YOLOv5 using the Pytorch framework. The open source code is available on [GitHub](#)

Author: [Glenn Jocher](#)

Released: 18 May 2020 <https://github.com/ultralytics/yolov5>

YOLOv4

With the original authors work on YOLO coming to a standstill, YOLOv4 was released by Alexey Bochoknovskiy, Chien-Yao Wang, and Hong-Yuan Mark Liao. The paper was titled [YOLOv4: Optimal Speed and Accuracy of Object Detection](#)

Author: [Alexey Bochoknovskiy](#), [Chien-Yao Wang](#), and [Hong-Yuan Mark Liao](#)

Released: 23 April 2020 YOLOv4 <https://arxiv.org/abs/2004.10934v1>

3- <https://www.kaggle.com/ultralitics/yolov5>

Version 14 of 14

[Notebook](#)

[Setup1.](#)

[Inference2.](#)

[Validate3.](#)

[Train4.](#)

[Visualize](#)

[Environments](#)

[Status](#)

[Appendix](#)

[Input \(1\)](#)

[Execution](#)

[Info](#) [Log](#)

4 - Yolov5 en Kaggle 1: Setup

Clone repo, install dependencies and check PyTorch and GPU.

```
!git clone https://github.com/ultralytics/yolov5 # clone repo
```

```
%cd yolov5
```

```
%pip install -qr requirements.txt # install dependencies
```

```
import torch
```

```
from IPython.display import Image, clear_output # to display images
```

```
clear_output()
```

```
print(f"Setup complete. Using torch {torch.__version__}
```

```
({torch.cuda.get_device_properties(0).name if torch.cuda.is_available() else 'CPU'})")
```

5 - yolov5 - 2. Inference

detect.py runs YOLOv5 inference on a variety of sources, downloading models automatically from the latest YOLOv5 release, and saving results to runs/detect

. Example inference sources are:

```
$ python detect.py --source 0 # webcam
                        file.jpg # image
                        file.mp4 # video
                        path/    # directory
                        path/*.jpg # glob
                        'https://youtu.be/NUsoVlDFqZg' # YouTube video
                        'rtsp://example.com/media.mp4'  # RTSP, RTMP, HTTP stream
```

```
!python detect.py --weights yolov5s.pt --img 640 --conf 0.25 --source data/images/
Image(filename='runs/detect/exp/zidane.jpg', width=600)
```

5 - yolov5 - 2. Inference

```
detect: weights=['yolov5s.pt'], source=data/images/, imgsz=640, conf_thres=0.25, iou_thres=0.45, max_det=1000, device=, view_img=False, save_txt=False, save_conf=False,
save_crop=False, nosave=False, classes=None, agnostic_nms=False, augment=False, visualize=False, update=False, project=runs/detect, name=exp, exist_ok=False,
line_thickness=3, hide_labels=False, hide_conf=False, half=False
```

Downloading https://github.com/ultralytics/yolov5/releases/download/v5.0/yolov5s.pt to yolov5s.pt...
100%|███████████ | 14.1M/14.1M [00:00<00:00, 100MB/s]

```
image 1/2 /kaggle/working/yolov5/data/images/bus.jpg: 640x480 4 persons, 1 bus, 1 fire hydrant, Done. (0.043s)
image 2/2 /kaggle/working/yolov5/data/images/zidane.jpg: 384x640 2 persons, 2 ties, Done. (0.028s)
Results saved to runs/detect/exp
Done. (0.199s)
```



6- yolov5 - 3. Validate

Validate a model's accuracy on COCO val or test-dev datasets. Models are downloaded automatically from the latest YOLOv5 release. To show results by class use the `--verbose` flag. Note that pycocotools metrics may be ~1% better than the equivalent repo metrics, as is visible below, due to slight differences in mAP computation.

COCO val2017

Download COCO val 2017 dataset (1GB - 5000 images), and test model accuracy.

```
# Download COCO val2017
```

```
torch.hub.download_url_to_file('https://github.com/ultralytics/yolov5/releases/download/v1.0/coco2017val.zip', 'tmp.zip')
```

```
!unzip -q tmp.zip -d ../datasets && rm tmp.zip
```

```
# Run YOLOv5x on COCO val2017
```

```
!python val.py --weights yolov5x.pt --data coco.yaml --img 640 --iou 0.65 --half
```


6- yolov5 - 3. Validate

```
val: data=./data/coco.yaml, weights=['yolov5x.pt'], batch_size=32, imgsz=640, conf_thres=0.001,  
iou_thres=0.65, task=val, device=, single_cls=False, augment=False, verbose=False, save_txt=False,  
save_hybrid=False, save_conf=False, save_json=True, project=runs/val, name=exp, exist_ok=False,  
half=True  
Downloading https://github.com/ultralytics/yolov5/releases/download/v5.0/yolov5x.pt to yolov5x.pt...  
100%|██████████████████████████████████████| 168M/168M  
[00:02<00:00, 81.6MB/s]
```

```
val: Scanning '../datasets/coco/val2017' images and labels...4952 found, 48 miss
      Class  Images  Labels      P      R  mAP@.5 mAP@val.py:61: UserWarning: This overload
of nonzero is deprecated:
      nonzero()
Consider using one of the following signatures instead:
      nonzero(*, bool as_tuple) (Triggered internally at /opt/conda/conda-
bld/pytorch_1603729047590/work/torch/csrc/utils/python_arg_parser.cpp:882.)
      ti = (cls == tcls).nonzero().view(-1) # label indices
      Class  Images  Labels      P      R  mAP@.5 mAP@
```

7- yolov5 - 4. COCO test-dev2017

Download COCO test2017 dataset (7GB - 40,000 images), to test model accuracy on test-dev set (20,000 images, no labels). Results are saved to a *.json file which should be zipped and submitted to the evaluation server at <https://competitions.codalab.org/competitions/20794>.

```
# Download COCO test-dev2017
torch.hub.download_url_to_file('https://github.com/ultralytics/yolov5/releases/download/v1.0/coco2017labels.zip', 'tmp.zip')
!unzip -q tmp.zip -d ./ && rm tmp.zip # unzip labels
!f="test2017.zip" && curl http://images.cocodataset.org/zips/$f -o $f && unzip -q $f
&& rm $f # 7GB, 41k images
%mv ./test2017 ./coco/images # move to /coco
# Run YOLOv5s on COCO test-dev2017 using --task test
!python val.py --weights yolov5s.pt --data coco.yaml --task test
```

<https://github.com/ultralytics/yolov5/wiki/Train-Custom-Data>

7- yolov5 - 4. COCO test-dev2017

<https://github.com/ultralytics/yolov5/wiki/Train-Custom-Data>

Train On Custom Data

1. Create dataset.yaml

COCO128 is an example small tutorial dataset composed of the first 128 images in COCO train2017. These same 128 images are used for both training and validation to verify our training pipeline is capable of overfitting. data/coco128.yaml, shown below, is the dataset config file that defines 1) the dataset root directory path and relative paths to train / val / test image directories (or *.txt files with image paths), 2) the number of classes nc and 3) a list of class names:

```
# Train/val/test sets as 1) dir: path/to/imgs, 2) file: path/to/imgs.txt, or 3) list: [path/to/imgs1, path/to/imgs2, ..]
```

```
path: ../datasets/coco128 # dataset root dir
```

```
train: images/train2017 # train images (relative to 'path') 128 images
```

```
val: images/train2017 # val images (relative to 'path') 128 images
```

```
test: # test images (optional)
```

Classes

nc: 80 # number of classes

```
names: [ 'person', 'bicycle', 'car', 'motorcycle', 'airplane', 'bus', 'train', 'truck', 'boat', 'traffic light',  
        'fire hydrant', 'stop sign', 'parking meter', 'bench', 'bird', 'cat', 'dog', 'horse', 'sheep', 'cow',  
        'elephant', 'bear', 'zebra', 'giraffe', 'backpack', 'umbrella', 'handbag', 'tie', 'suitcase', 'frisbee',  
        'skis', 'snowboard', 'sports ball', 'kite', 'baseball bat', 'baseball glove', 'skateboard', 'surfboard',  
        'tennis racket', 'bottle', 'wine glass', 'cup', 'fork', 'knife', 'spoon', 'bowl', 'banana', 'apple',  
        'sandwich', 'orange', 'broccoli', 'carrot', 'hot dog', 'pizza', 'donut', 'cake', 'chair', 'couch',  
        'potted plant', 'bed', 'dining table', 'toilet', 'tv', 'laptop', 'mouse', 'remote', 'keyboard', 'cell phone',  
        'microwave', 'oven', 'toaster', 'sink', 'refrigerator', 'book', 'clock', 'vase', 'scissors', 'teddy bear',  
        'hair drier', 'toothbrush' ] # class names
```

8- yolov5 - 5. Train

Download COCO128, a small 128-image tutorial dataset, start tensorboard and train YOLOv5s from a pretrained checkpoint for 3 epochs (note actual training is typically much longer, around 300-1000 epochs, depending on your dataset).

```
# Download COCO128
```

```
torch.hub.download_url_to_file('https://github.com/ultralytics/yolov5/releases/download/v1.0/coco128.zip', 'tmp.zip')
```

```
!unzip -q tmp.zip -d ../ && rm tmp.zip
```

9- yolov5 - 5. Train

Train a YOLOv5s model on COCO128 with `--data coco128.yaml`, starting from pretrained `--weights yolov5s.pt`, or from randomly initialized `--weights '' --cfg yolov5s.yaml`. Models are downloaded automatically from the latest YOLOv5 release, and COCO, COCO128, and VOC datasets are downloaded automatically on first use.

All training results are saved to `runs/train/` with incrementing run directories, i.e. `runs/train/exp2`, `runs/train/exp3` etc.

10- yolov5 - 5. Train


```
# Tensorboard (optional)
%load_ext tensorboard
%tensorboard --logdir runs/train
# Weights & Biases (optional)
%pip install -q wandb
import wandb
wandb.login()
# Train YOLOv5s on COCO128 for 3 epochs
!python train.py --img 640 --batch 16 --epochs 3 --data coco128.yaml --weights yolov5s.pt --cache
```

11- yolov5 - Weights & Biases Logging

Weights & Biases (W&B) is now integrated with YOLOv5 for real-time visualization and cloud logging of training runs. This allows for better run comparison and introspection, as well improved visibility and collaboration for teams. To enable W&B pip install wandb, and then train normally (you will be guided through setup on first use).

During training you will see live updates at <https://wandb.ai/home>, and you can create and share detailed Reports of your results. For more information see the YOLOv5 Weights & Biases Tutorial.

12- yolov5 - Weights & Biases Logging



13- yolov5 - Local Logging

Local Logging


All results are logged by default to runs/train, with a new experiment directory created for each new training as runs/train/exp2, runs/train/exp3, etc. View train and val jpgs to see mosaics, labels, predictions and augmentation effects. Note a Mosaic Dataloader is used for training (shown below), a new concept developed by Ultralytics and first featured in YOLOv4.

```
Image(filename='runs/train/exp/train_batch0.jpg', width=800) # train batch 0 mosaics and labels
```

```
Image(filename='runs/train/exp/test_batch0_labels.jpg', width=800) # val batch 0 labels
```

```
Image(filename='runs/train/exp/test_batch0_pred.jpg', width=800) # val batch 0 predictions
```


14- yolov5 - Mosaic Dataloader



Training results are automatically logged to Tensorboard and runs/train/exp/results.txt, which is plotted as results.png (below) after training completes.

15- yolov5 - You can also plot any results.txt file manually:

```
from utils.plots import plot_results
plot_results(save_dir='runs/train/exp') # plot all results*.txt files in 'runs/train/exp'
Image(filename='runs/train/exp/results.png', width=800)
```



16- status

CI tests verify correct operation of YOLOv5 training (train.py), testing (val.py), inference (detect.py) and export (export.py) on MacOS, Windows, and Ubuntu every 24 hours and on every commit.

17- yolov5

Appendix¶

Optional extras below. Unit tests validate repo functionality and should be run on any PRs submitted.

Reproduce

```
for x in 'yolov5s', 'yolov5m', 'yolov5l', 'yolov5x':
```

```
    !python val.py --weights {x}.pt --data coco.yaml --img 640 --conf 0.25 --iou 0.45 # speed
```

```
    !python val.py --weights {x}.pt --data coco.yaml --img 640 --conf 0.001 --iou 0.65 # mAP
```

PyTorch Hub

```
import torch
```

Model

```
model = torch.hub.load('ultralytics/yolov5', 'yolov5s')
```

Images

```
dir = 'https://ultralytics.com/images/'
```

```
imgs = [dir + f for f in ('zidane.jpg', 'bus.jpg')] # batch of images
```

Inference

```
results = model(imgs)
```

```
results.print() # or .show(), .save()
```

18- yolov5

Unit tests

```
%%shell
```

```
export PYTHONPATH="$PWD" # to run *.py. files in subdirectories
```

```
rm -rf runs # remove runs/
```

```
for m in yolov5s; do # models
```

```
python train.py --weights $m.pt --epochs 3 --img 320 --device 0 # train pretrained
```

```
python train.py --weights "" --cfg $m.yaml --epochs 3 --img 320 --device 0 # train scratch
```

```
for d in 0 cpu; do # devices
```

```
python detect.py --weights $m.pt --device $d # detect official
```

```
python detect.py --weights runs/train/exp/weights/best.pt --device $d # detect custom
```

```
python val.py --weights $m.pt --device $d # val official
```

```
python val.py --weights runs/train/exp/weights/best.pt --device $d # val custom
```

```
done
```

```
python hubconf.py # hub
```

```
python models/yolo.py --cfg $m.yaml # inspect
```

```
python export.py --weights $m.pt --img 640 --batch 1 # export
```

```
done
```

19- yolov5

```
# Profile
from utils.torch_utils import profile

m1 = lambda x: x * torch.sigmoid(x)
m2 = torch.nn.SiLU()
profile(x=torch.randn(16, 3, 640, 640), ops=[m1, m2], n=100)
# Evolve
!python train.py --img 640 --batch 64 --epochs 100 --data coco128.yaml --weights
yolov5s.pt --cache --noautoanchor --evolve
!d=runs/train/evolve && cp evolve.* $d && zip -r evolve.zip $d && gsutil mv evolve.zip
gs://bucket # upload results (optional)
# VOC
for b, m in zip([64, 48, 32, 16], ['yolov5s', 'yolov5m', 'yolov5l', 'yolov5x']): #
zip(batch_size, model)
    !python train.py --batch {b} --weights {m}.pt --data VOC.yaml --epochs 50 --cache --img
512 --nosave --hyp hyp.finetune.yaml --project VOC --name {m}
```

20 # Introduction

This directory contains software developed by Ultralytics LLC, and **is freely available for redistribution under the GPL-3.0 license**. For more information please visit <https://www.ultralytics.com>.

Description

The <https://github.com/ultralytics/COCO2YOLO> repo contains code to convert JSON datasets into YOLO (darknet) format. The code works on Linux, MacOS and Windows.

Requirements

Python 3.7 or later with the following ``pip3 install -U -r requirements.txt`` packages:

- ``numpy``
- ``tqdm``

Citation

[![DOI](https://zenodo.org/badge/186122711.svg)](https://zenodo.org/badge/latestdoi/186122711)

Contact

Issues should be raised directly in the repository. For additional questions or comments please email Glenn Jocher at glenn.jocher@ultralytics.com or visit us at <https://contact.ultralytics.com>.

Concurso Kaggle

ejercicio (paso a paso)

<https://www.kaggle.com/clauidorparrinello/siim-covid-19-yolo-v5-image-level-predictions/>

1- paso1

1

#creating new directory

%cd ../

!mkdir siim_covid19

Reason for creating & moving into this directory can be seen in above folder structure

%cd siim_covid19

!git clone <https://github.com/ultralytics/yolov5> # clone repo

%cd yolov5

!pip install -r requirements.txt

moving back to working directory

%cd ../

2- Salvando logs en W&B paso2

2

```
##-----
```

```
#Not saving logs into W&B
```

```
##-----
```

```
# Access WANDB account
```

```
#!pip install -q --upgrade wandb
```

```
#import wandb
```

```
#wandb.login()
```

3- Copiando yolov5 e instalando (# pip install -r requirements.txt)

```
# pip install -r requirements.txt
```

```
# base -----
```

```
matplotlib>=3.2.2
```

```
numpy>=1.18.5
```

```
opencv-python>=4.1.2
```

```
Pillow
```

```
PyYAML>=5.3.1
```

```
scipy>=1.4.1
```

```
torch>=1.7.0
```

```
torchvision>=0.8.1
```

```
tqdm>=4.41.0
```

```
# logging -----
```

```
tensorboard>=2.4.1
```

```
# wandb
```

```
# plotting -----
```

```
seaborn>=0.11.0
```

```
pandas
```

```
# export -----
```

```
# coremltools>=4.1
```

```
# onnx>=1.9.0
```

```
# scikit-learn==0.19.2 # for coreml quantization
```

```
# extras -----
```

```
# Cython # for pycocotools https://github.com/cocodataset/cocoapi/issues/172
```

```
# pycocotools>=2.0 # COCO mAP
```

```
# alumentations>=1.0.3
```

```
thop # FLOPs computation
```

```
© 2021 GitHub, Inc.
```

4- Copiando modelos yolov5

4

Inference with YOLOv5 and [PyTorch Hub](https://pytorch.org/hub/). Models automatically download from the [latest YOLOv5 release](https://github.com/ultralytics/yolov5/releases).
<https://github.com/ultralytics/yolov5/releases>

Model

```
model = torch.hub.load('ultralytics/yolov5', 'yolov5s') # or yolov5m, yolov5l, yolov5x, custom
```

Images

```
img = 'https://ultralytics.com/images/zidane.jpg' # or PosixPath, PIL, OpenCV, numpy, list
```

Inference

```
results = model(img)
```

Results

```
results.print() # or .show(), .save(), .crop(), .pandas(), etc.
```

5- Copiando yolov5 - Pretrained Checkpoints

| Model | size (pixel) | mAP ^{val} 0.5:0.95 | mAP ^{test} 0.5:0.95 | mAP ^{val} 0.5 | Speed V100 (ms) | params (M) | FLOPS 640 (B) |
|----------------------------------|-----------------|--------------------------------|---------------------------------|---------------------------|--------------------|---------------|------------------|
| YOLOv5s | 640 | 36.7 | 36.7 | 55.4 | 2.0 | 7.3 | 17.0 |
| YOLOv5m | 640 | 44.5 | 44.5 | 63.1 | 2.7 | 21.4 | 51.3 |
| YOLOv5l | 640 | 48.2 | 48.2 | 66.9 | 3.8 | 47.0 | 115.4 |
| YOLOv5x | 640 | 50.4 | 50.4 | 68.8 | 6.1 | 87.7 | 218.8 |
| YOLOv5s6 | 1280 | 43.3 | 43.3 | 61.9 | 4.3 | 12.7 | 17.4 |
| YOLOv5m6 | 1280 | 50.5 | 50.5 | 68.7 | 8.4 | 35.9 | 52.4 |
| YOLOv5l6 | 1280 | 53.4 | 53.4 | 71.1 | 12.3 | 77.2 | 117.7 |
| YOLOv5x6 | 1280 | 54.4 | 54.4 | 72.0 | 22.4 | 141.8 | 222.9 |
| YOLOv5x6 TT A | 1280 | 55.0 | 55.0 | 72.0 | 70.8 | - | |

6- Inference with detect.py

6

detect.py runs inference on a variety of sources, downloading models automatically from the latest YOLOv5 release and saving results to runs/detect.

```
$ python detect.py --source 0 # webcam  
    file.jpg # image  
    file.mp4 # video  
    path/ # directory  
    path/*.jpg # glob  
    'https://youtu.be/NUsoVIDFqZg' # YouTube video  
    'rtsp://example.com/media.mp4' # RTSP, RTMP, HTTP stream
```

Importing Dependencies

```
import os
import shutil
import tensorflow as tf
import yaml
```

```
import numpy as np
import pandas as pd
from sklearn.model_selection import train_test_split
import ast
```

```
import matplotlib.pyplot as plt
import cv2
import PIL
```

```
import warnings
warnings.filterwarnings('ignore')
```


Importing Dependencies

```
TRAIN_PATH = "../input/siim-covid19-dataset-256px-  
jpg/512px/train/train/"  
HEIGHT,WIDTH = 512,512  
CHANNELS = 3  
BATCH_SIZE = 16  
EPOCHS = 40  
SEED =2021
```

CSV file

```
# Get image path from image_id
def get_path(image_id):
    path = tf.io.gfile.glob(TRAIN_PATH + f"*{image_id}.jpg")[0]
    return path

image_dict = {
    "opacity" : 1,
    "none" : 0
}

df = pd.read_csv("../input/siim-covid19-dataset-256px-jpg/train.csv")

df["image_label"] = df["image_label"].map(lambda x : x.split(" ")[0])
df["image_label_id"] = df["image_label"].map(lambda x : image_dict[x])
df["filepath"] = df["ImageInstanceUID"].map(get_path)
df.head(3)
```

Splitting Data

```
train_df, val_df = train_test_split(df,  
                                   test_size=0.2,  
                                   random_state = SEED,  
                                   stratify = df.image_label.values  
                                   )
```

```
train_df.loc[:, "data"] = "train"  
val_df.loc[:, "data"] = "val"  
df = pd.concat([train_df, val_df]).reset_index(drop=True)
```

Preparing folder structure

```
os.makedirs('../siim_covid19/dataset/images/train', exist_ok=True)
os.makedirs('../siim_covid19/dataset/images/val', exist_ok=True)
```

```
os.makedirs('../siim_covid19/dataset/labels/train', exist_ok=True)
os.makedirs('../siim_covid19/dataset/labels/val', exist_ok=True)
print("Created folder structure")
```

```
IMAGE_PATH = "../siim_covid19/dataset/images"
for i in df.values:
    data = i[10]
    img_name = i[9].split("/")[-1]
    shutil.copyfile(i[9], f"{IMAGE_PATH}/{data}/{img_name}")
```

Creating YAML file

REF : <https://www.kaggle.com/ayuraj/train-covid-19-detection-using-yolov5>

```
yaml_dict = dict(  
    train = "../dataset/images/train",  
    val = "../dataset/images/val",  
    nc = 2,  
    names = ["none", "opacity"]  
)
```

```
with open("../siim_covid19/yolov5/data/data.yaml", "w") as f:  
    yaml.dump(yaml_dict, f, default_flow_style=True)
```

Preprocessing Bounding Boxes

```
df["boxes"] = df["boxes"].map(lambda x : ast.literal_eval(x))
```

```
def preprocess_bbox(row):
```

```
    factor_x = 1/row[5]
```

```
    factor_y = 1/row[4]
```

```
    bboxes = []
```

```
    if row[7] == "opacity":
```

```
        for box in row[6]:
```

```
            x = box["x"]*factor_x
```

```
            y = box["y"]*factor_y
```

```
            w = box["width"]*factor_x
```

```
            h = box["height"]*factor_y
```

```
            xc = x + w/2
```

```
            yc = y + h/2
```

```
            bboxes.append([xc,yc,w,h])
```

```
    return bboxes
```

Preprocessing Bounding Boxes

```
# Prepare txt files
LABEL_PATH = "../siim_covid19/dataset/labels"
for row in df.values:
    filename = row[9].split("/)[-1][:4]
    filepath = f"{LABEL_PATH}/{row[10]}/{filename}.txt"

    if row[7] == "opacity":
        bbox = preprocess_bbox(row)
        with open(filepath, "w") as f:
            for box in bbox:
                box = [1] + box
                box = [str(i) for i in box]
                box = ' '.join(box)
                f.write(box)
                f.write('\n')
```

Training

```
%cd yolov5/  
!wandb off  
!python train.py --img {HEIGHT} \  
    --batch {BATCH_SIZE} \  
    --epochs {EPOCHS} \  
    --data data.yaml \  
    --weights yolov5s.pt \  
    --save_period 1\  
    --name yolov5_training
```

```
print("Training Completed")
```

```
%cd ../../  
train_ls =  
tf.io.gfile.glob("./siim_covid19/yolov5/runs/train/yolov5_traini  
ng/*.g")
```

```
os.makedirs("./working/train_results", exist_ok=True)  
for filepath in train_ls:  
    name = filepath.split("/")[-1]  
    shutil.copyfile(filepath, "./working/train_results/"+name)
```

```
shutil.copyfile("./siim_covid19/yolov5/runs/train/yolov5_traini  
ng/weights/best.pt", "./working/best_yolov5.pt")  
print("Training curves moved to output directory")
```


Inference

```
TEST_PATH = "/kaggle/input/siim-covid19-dataset-256px-jpg/224px/test/test"
BEST_MODEL_PATH = "./runs/train/yolov5_training/weights/best.pt"
```

```
%cd ./siim_covid19/yolov5
!python detect.py --weights {BEST_MODEL_PATH} \
    --source {TEST_PATH} \
    --img {HEIGHT} \
    --conf 0.3 \
    --iou-thres 0.5 \
    --max-det 3 \
    --save-txt \
    --save-conf \
    --name yolov5_testing
```

```
print("Predictions Completed")
```

Format of txt file of output

label_id x_center y_center width height

Sample Prediction

```
PREDICTIONS_PATH = "runs/detect/yolov5_testing/labels/"
PRED_FILES = os.listdir(PREDICTIONS_PATH)

print("Sample prediction (in txt file) : \n")

with open(PREDICTIONS_PATH + PRED_FILES[0], "r") as f:
    ls = f.read().strip("\n").split(" ")
    print(f"LABEL : {ls[0]} \nX_CENTER : {ls[1]} \nY_CENTER : {ls[2]} \nWIDTH : {ls[3]} \nHEIGHT : {ls[4]} \nCONFIDENCE : {ls[5]}")
print("Number of Prediction file originally present : ",len(PRED_FILES))
```

Creating txt files for "none" class

```
IMAGE_FILES = tf.io.gfile.glob("runs/detect/yolov5_testing/*.jpg")
ACTUAL_FILES = []
for path in IMAGE_FILES:
    ls = path.split("/")
    name = ls[-1].split(".")[0] + ".txt"
    ACTUAL_FILES.append(PREDICTIONS_PATH + name)

for filepath in ACTUAL_FILES:
    if not os.path.exists(filepath):
        with open(filepath, "w") as f:
            f.write("0 0 0 1 1 1")
            f.close()
```

Preprocessing functions

```
##-----
#getting string of predictions from txt file
##-----
def get_string(filepath,out= "bbox"):
    probs = []
    bboxes = []
    labels = []
    with open(filepath, "r") as f:
        for line in f:
            ls = line.strip("\n").split(" ")
            ls = list(map(float, ls))
            labels.append(ls[0])
            bboxes.append(ls[1:-1])
            probs.append(ls[-1])
    if out == "bbox":
        return bboxes
    elif out == "label":
        return labels
    else:
        return probs
```

```
##-----
#Scaling-up bounding box co-ordinates
##-----
def scale_bbox(row):
    scale_x = row[5]
    scale_y = row[6]
    scale_bboxes = []
    for box in row[1]:
        if row[2][0] != 0.0:
            xc,yc = box[0]*scale_x,box[1]*scale_y
            w,h = box[2]*scale_x,box[3]*scale_y
            xmin,ymin = int(xc - w/2),int(yc - h/2)
            xmax,ymax = int(xc + w/2),int(yc + h/2)
            scale_bboxes.append([xmin,ymin,xmax,ymax])
        else:
            return [[0,0,1,1]]
    return scale_bboxes
```

Preprocessing prediction csv file

```
pred_df = pd.DataFrame.from_dict({"filepath" : ACTUAL_FILES})
pred_df["bboxes"] = pred_df["filepath"].map(lambda x: get_string(x,out="bbox"))
pred_df["label"] = pred_df["filepath"].map(lambda x: get_string(x,out="label"))
pred_df["confidence"] = pred_df["filepath"].map(lambda x:
get_string(x,out="conf"))

pred_df["ImageInstanceUID"] = pred_df["filepath"].map(lambda x : x.split("/")[-
1].split("_")[-1][:4])

#%cd ../
meta_df = pd.read_csv("/kaggle/input/siim-covid19-dataset-256px-
jpg/meta_test.csv")
pred_df = pred_df.merge(meta_df, on = "ImageInstanceUID")

box_ls = []
for i,row in enumerate(pred_df.values):
    box_ls.append(scale_bbox(row))

pred_df["scale_bboxes"] = box_ls

pred_df.head(3)
```

Final Study Level Predictions

Final Study Level Predictions

```
%cd ../../../  
image_dict = {  
    0. : "none",  
    1. : "opacity"  
}
```

```
def get_string(row):  
    string = ""  
    if row[2][0] == 0.:  
        string += "none 1 0 0 1 1"  
        return string  
    for i in range(len(row[2])):  
        string += "opacity "  
        string += str(row[3][i])  
        string += " "  
        bbox = map(str,row[7][i])  
        tmp = " ".join(bbox)  
        string += tmp  
        string += " "  
    return string
```

```
strings = []  
for row in pred_df.values:  
    strings.append(get_string(row))
```

```
test_df = pd.DataFrame.from_dict({"Id" : pred_df["ImageInstanceUID"]})  
test_df["Id"] = test_df['Id'].map(lambda x : x+"_image")  
test_df["PredictionString"] = strings  
test_df.to_csv("kaggle/working/study_level_pred.csv",index = False)  
test_df.head()
```

Información yolov5

GENERALES 1

CI tests verify correct operation of YOLOv5 training ([train.py](#)), validation ([val.py](#)), inference ([detect.py](#)) and export ([export.py](#)) on MacOS, Windows, and Ubuntu every 24 hours and on every commit.

<https://towardsdatascience.com/yolo-v5-object-detection-tutorial-2e607b9013ef>

<https://jooskorstanje.com/yolov5-training-a-custom-object-detection-model.html>